AIRCRAFT PARKING/
DOCKING CHART

TWR 118.2 (North Runway)
118.4 (South Runway)

GMC 121.6 (North)
122.55 (South)

VHHH/ HONG KONG
INTERNATIONAL AIRPORT



LOCATION

SCALE 1:75 000

RUNWAY HOLDING POINT	═══
INTERMEDIATE HOLDING POSITION	———
TAXIWAY CENTRELINE	——— TWY A ———

METRES 100 50 0 100 200 300 400 500 600 700 800 METERS